

Paragon I and II

Please review the Release Notes for important release information. Please consult the Quick Setup Guide, and User Guide for product information on setup instructions, implementation, and operations. Paragon documents can be under Product Documentation at www.raritan.com/support/

Component	Firmware	Paragon I	Paragon II	P2-HUBPAC	Hubpac8-RK
		HW3 (P2 FW 3E3*)	HW4M (3E3 FW)	0C2	
CIM					
UKVMPD	0B7	Yes	Yes	Yes	Yes
UKVMP	0B7	Yes	Yes	Yes	Yes
UKVMC	0B7	Yes	Yes	Yes	Yes
UKVMP2	0A3	No	No	No	No
CIMPAC8-RK	0A3	No	No	No	No
UKVMP-x330	0B3	No	No	No	No
UKVMC-x330	0B3	No	No	No	No
UKVMSPD	0A5	Yes	Yes	No	No
USKVMPD	0C51	Yes	Yes	No	Yes
USKVMP	0C51	Yes	Yes	No	Yes
USKVMPA	0C51	Yes	Yes	No	No
USKVMC	0C51	Yes	Yes	No	Yes
UUSBPD	4CA	Yes	Yes	No	No
AUPUSBC	4CA	Yes	Yes	No	No
AUATC	2.59	No	Yes	No	No
P2CIM-PS2	2A6	Yes	Yes	Yes	No
P2CIM-SUN	2A2	Yes	Yes	Yes	No
P2CIM-USB	2A6	Yes	Yes	No	No
P2CIM-SUSB	0B1	Yes	Yes	No	No
P2CIM-PS2DUAL	2A3	Yes	Yes	No	No
P2CIM-AUSB	0C0	Yes	Yes	Yes	No
P2CIM-APS2	3B6	Yes	Yes	Yes	No
P2CIM-ASUN	3A4	Yes	Yes	Yes	No
P2CIM-APS2DUAL	2A3	Yes	Yes	No	No
P2CIM-PWR	0A4	No	Yes	No	No
P2CIM-USBG2	0C0	Yes	Yes	Yes	No
P2ZCIM-PS2	0B8	Yes	Yes	No	No
P2ZCIM-SUN	0B9	Yes	Yes	No	No
P2ZCIM- USB	0B8	Yes	Yes	No	No
Hubpac8-RK	0B4	No	No	No	NA
P2-Hubpac	0C2	Yes	Yes	NA	No

* Customers who do not have 3B0K firmware must update to this firmware first and then 3E3 which will ensure that the proper boot loaders are installed.

Component	Firmware	Paragon I	Paragon II	P2-HUBPAC	Hubpac8-RK
		HW3 (P2 FW 3E2*)	HW4M (3E2 FW)	0C2	
User Stations					
P2-UST	1DF	Yes UMT-3B0K and above/UST- 1A7 and above	Yes	Yes	No
P2-EUST	3E2	Yes UMT-3E0 and above	Yes, UMT-3E0 and above	Yes	No
UST1	5J1	Yes w/ 5J1 FW/ FPGA-0C** and above	Yes w/ 5J1 FW/ FPGA-0C and above	No	Yes
P2-USTIP1/2	1.2.0.5	Yes w/ RRC FW 4.6.2.5.9 & MPC FW 4.6.2.5.12	Yes w/ RRC FW 4.6.2.5.9 & MPC FW 4.6.2.5.12	Yes	No

* Customers who do not have 3B0K firmware must update to this firmware first and then 3E3 which will ensure that the proper boot loaders are installed.

** Some original Paragon I UST1 versions may be limited in terms of upgrading to Paragon II. If the FPGA Ver is OB (from the UST click F8 to get the Information Menu) it can not be upgraded.

Tiering Chart

		BASE TIER			
		UMTx HW2 w/ 2C3 FW	UMTx HW3 w/3A3 FW	UMTx HW3 w/3.2 FW ²	P2-UMT1664M/ 832M/442/242
Upper/Lower Tiers	P2-UMT1664M / 832M/442/242	No	No	No	Yes
	P2-UMT1664S/832 S ¹	No	No	Yes - Stack ¹	Yes - Stack ¹
	UMTx HW3 w/3.2 FW ²	No	No	Yes	Yes
	UMTx HW3 w/3A3 FW	No	Yes	Yes	Yes
	UMTx HW2	Yes	Yes	Yes	Yes
	UKVMSPD Z- CIM	Yes	Yes	Yes	Yes
	P2ZCIM	No	No	Yes	Yes
	AUATC	Yes	Yes	No	Yes
	IBMX-330	Yes	Yes	No	No
	Hubpac	Yes	Yes	No	No
	P2-Hubpac	No	No	Yes	Yes

In general, the latest hardware and firmware must be on the lowest tier

- Stacking units have no user ports, so it can not be cascaded as an upper tier to a lower tier switch
- UMTxHW3 has no memory card slot, so maximum targets/expandability will be 1800 targets